



Figure 1: FLEX Multibus RS485 module

CON 3	
Pin 1	-
Pin 2	RS485-
Pin 3	RS485+
Pin 4	-
Pin 5	GND

Jumper	pos. 1-2	pos. 2-3
JP1	LOOPBACK	-
JP2	TXEN_dsPIC	TXEN_GND
JP3	TXEN_dsPIC	TXEN_+5V

Note: Default jumper settings are indicated with grey background

CON 1	
Pin 1	+5V
Pin 2	TX
Pin 3	TXEN
Pin 4	RX
Pin 5	-
Pin 6	GND