



Figure 1: FLEX Multibus SPI module

CON 3	
Pin 1	SPI_DO_C
Pin 2	SPI_DI_C
Pin 3	SPI_CLK_C
Pin 4	SPI_SS_C
Pin 5	GND

Jumper	pos. 1-2	pos. 2-3
JP1	SPI_DO	GND
JP2	SPI_CLK	GND
JP3	SPI_DO_C	GND
JP4	SPI_SS	GND

Note: Default jumper settings are indicated with grey background

CON 2	
Pin 1	+5V
Pin 2	SPI_DO
Pin 3	SPI_DI
Pin 4	SPI_CLK
Pin 5	SPI_SS
Pin 6	GND